

Replacing Manifold with Ball Valve (shut-off) and Quick Disconnect

Add orange plastic Plug when disconnecting 5/32 tubing, to keep dirt out of union
Part Number 639PL-5/32

Union splice
P/N 62PL-532

Manifold
Part Number 170-4515

Ball Valve
Part Number 012-2F2F-BT

Nipple (Male to Male)
Part Number 216P-2



Note:

- Remove Manifold on Pump and replace with components
- Starting with the nipple.
- Reminder—you can NOT put two Ball valves next to each other on top of pump

Suburban Manufacturing Inc
301 Chelsea Road
Monticello, MN 55362

Rocco Frucci - Sales and Tech Support
Toll Free: 1-800-782-5752
Phone: 763-295-5635
Fax: 763-295-6601